


# SHOP MANUAL

## HONDA ODYSSEY FL 250



**'81**

## IMPORTANT SAFETY NOTICE

**WARNING**

*Indicates a strong possibility of severe personal injury or loss of life if instructions are not followed.*

**CAUTION**

*Indicates a possibility of personal injury or equipment damage if instructions are not followed.*

Detailed descriptions of standard workshop procedures, safety principles and service operations are not included. It is important to note that this manual contains *some* warnings and cautions against some specific service methods which could cause **PERSONAL INJURY** to service personnel or could damage a vehicle or render it unsafe. Please understand that those warnings could not cover all conceivable ways in which service, whether or not recommended by Honda might be done or of the possible hazardous consequences of each conceivable way, nor could Honda investigate all such ways. Anyone using service procedures or tools, whether or not recommended by Honda *must satisfy himself thoroughly* that neither personal safety nor vehicle safety will be jeopardized by the service method or tools selected.



**HONDA**  
**FL 250**

## TABLE OF CONTENTS

<b>1 . GENERAL INFORMATION</b>	
A. Frame/Engine Number Identifications and Number Locations .....	<b>1 -1</b>
B. Lift and Support Points .....	<b>1 -2</b>
<b>2 . TECHNICAL FEATURES.....</b>	<b>2 -1</b>
<b>3 . SPECIAL TOOLS .....</b>	<b>3 -1</b>
<b>4 . SERVICE DATA</b>	
A. Required Maintenance Schedule .....	<b>4 -1</b>
B. Lubrication Points.....	<b>4 -2</b>
<b>5 . TECHNICAL DATA</b>	
A. Standard Tolerances and Wear Limit.....	<b>5 1</b>
B. Torque Specifications .....	<b>5 -2</b>
<b>6 . GENERAL DATA</b>	
A. Overall Vehicle Dimensions.....	<b>6 -1</b>
B. General Specifications.....	<b>6 -2</b>
<b>7 . ENGINE REMOVAL/INSTALLATION .....</b>	<b>7 -1</b>
<b>8 . ENGINE .....</b>	<b>8 -1</b>
<b>9 . FRAME .....</b>	<b>9 -1</b>
<b>10. ELECTRICAL DIAGRAM.....</b>	<b>10-1</b>
<b>11. '80 ADDENDUM .....</b>	<b>11-1</b>
<b>12. '81 ADDENDUM .....</b>	<b>12-1</b>

1

2

3

4

5

6

7






# GENERAL INFORMATION

## A. Frame/Engine Number Identifications and Number Locations



### ENGINE SERIAL NUMBER IDENTIFICATION

FL250 E - 1000000

MODEL —  
ENGINE —  
SERIAL NUMBER —



ENGINE NUMBER




FRAME NUMBER

### FRAME NUMBER IDENTIFICATION

FL250 - 1000000


MODEL —  
SERIAL NUMBER —

**B. Lift and Support Points****FRONT**


FRONT HAS NO JACK POINTS  
LIFT HERE BY HAND

**WARNING**

Always use safety stands when working on or under a vehicle that is supported by only a jack.

**REAR**

JACK POINT

**CAUTION**


Four support points are provided as shown.



**HONDA**  
**FL 250**

2

## TECHNICAL FEATURES





**SPECIAL TOOLS****Frame**

TOOL NUMBER	DESCRIPTION	FIGURE REFERENCE
07946 – 3600000	Driver Attachment	1
07916 – 9180000	Tire Disassembly Tool	2
07944 – 9350300	6 mm Spring Pin Driver	3
07945 – 3330100	Driver Attachment	4
07959 – 3290000	Front Shock Absorber Compressor	5

**Engine**

TOOL NUMBER	DESCRIPTION	FIGURE REFERENCE
07923 – 0010000	Rotor Holder	6
07933 – 0010000	Rotor Puller	7
07945 – 3330300	Bearing Driver	8
07933 – 9500000	Case Puller	9

**Frame and Engine**

TOOL NUMBER	DESCRIPTION	FIGURE REFERENCE
07949 – 6110000	Driver Attachment Handle	10

**SALSBURY's belt converter**

TOOL NUMBER	DESCRIPTION	FIGURE REFERENCE
Salsbury #602112	SPANNER	11
#602090	CLUTCH PULLER TOOL	12
#703463	TAPER PLUG	13
#704229	SPIDER INSTALLATION CUP	14
#704233	PULLER PLATE	15
#900403	SCREW (1/4-20 x 2-3/4)	16
#704232	STEP PLUG	17
#901836	SCREW (1/2-20 x 5-1/2)	18
#703446	SPRING SEATING TOOL	19
#602114	SPECIAL SCREW	20
#901840	NUT (1/2-20)	21
#704236	FLAT WASHER	21
#704237	CAM RETAINER	22



## Frame


## REAR BRAKE



Driver Attachment  
07946 – 3600000  
[For installation of rear brake bearing  
and oil seal. Used with 07949 –  
6110000 (Fig. 10.)]

Fig. 1.

## TIRE



Tire Disassembly Tool  
07916 – 9180000  
(For disassembly of tire)


Fig. 2.

## FRONT SUSPENSION




6 mm Spring Pin Driver  
07944 – 9350300  
(For removal of front arm  
and pivot pipe.)

Fig. 3.



Driver Attachment  
07945 – 3330100  
[For installation of front  
hub bearing and oil seal.  
Used with 07949 –  
6110000 (Fig. 10.)]

Fig. 4.



Front Shock Absorber Compressor  
07959 – 3290000  
(For disassembly and Installation  
of front shock absorber.)

Fig. 5.




### Engine

### ROTOR



Rotor Holder  
07923 - 0010000  
(For disassembly and installation of  
rotor retaining nut)

Fig. 6




Rotor Puller  
07933 - 0010000  
(For removal of rotor)

Fig. 7


### CRANKSHAFT

### CRANKCASE



Bearing Driver  
07945 - 3330300  
[For installation of crankshaft bearing.  
Used with 07949-6110000 (Fig. 10) ]

Fig. 8




Case Puller  
07933 - 9500000  
(For disassembly of R/L crankcase)

Fig. 9

**FRAME AND ENGINE**

Driver Attachment Handle  
07949 – 6110000 [Used with  
07946 – 3600000 (Fig. 1),  
07945 – 3330100 (Fig. 4),  
07945 – 3330300 (Fig. 8) ]

Fig. 10

**BELT CONVERTER**

Spanner  
Salsbury #602112  
(For holding drive pulley)

Fig. 11

**BELT CONVERTER**

Clutch Puller Tool  
Salsbury #602090  
(For drive pulley dismounting)

Fig. 12

**BELT CONVERTER**


Taper Plug  
Salsbury #703463  
(For securing drive pulley)

Fig. 13






**BELT CONVERTER**



Spider Installation Cup  
Salsbury #704229  
(For spider installation)

Fig. 14

**BELT CONVERTER**



Puller Plate  
Salsbury #704233  
(For disassembly of spider and  
disassembly of driven pulley)

Fig. 15

**BELT CONVERTER**



Screw (1/4 - 20 x 2 - 3/4)  
Salsbury #900403  
(For use of puller plate when  
disassembling spider)

Fig. 16

**BELT CONVERTER**



Step Plug  
Salsbury #704232  
(For disassembling of spider)

Fig. 17

**BELT CONVERTER**

Screw (1/2 – 20 x 5-1/2)  
Salsbury #901836  
(For spider installation)

Fig. 18

**BELT CONVERTER**

Spring Seating Tool  
Salsbury #703446  
(For seating of roller arm return  
spring)

Fig. 19

**BELT CONVERTER**

Special Screw  
Salsbury #602114  
(For securing of driven pulley)

Fig. 20


**BELT CONVERTER**

Nut                      Salsbury #901840  
Flat Washer        Salsbury #704236  
(For disassembly and reassembly of  
driven pulley)

Fig. 21



**BELT CONVERTER**



Cam Retainer  
Salsbury # 704237  
(For retaining of driven pulley  
cam)

Fig. 22





## SERVICE DATA

### A. REQUIRED MAINTENANCE SCHEDULE

The maintenance intervals shown in the following schedule are based upon average riding conditions. Machines subjected to severe use, or ridden in unusually dusty areas, require more frequent servicing.

Items marked \* should be serviced by an authorized Honda dealer, unless the owner has proper tools and a HONDA ODYSSEY shop manual, and is mechanically proficient. Other maintenance items are simple to perform and may be serviced by the owner.

#### INITIAL SERVICE PERIOD (FIRST WEEK OR 15 HOURS OPERATION WHICHEVER COMES FIRST)


- \*CONTACT POINTS AND IGNITION TIMING – Clean, check, and adjust or replace if necessary.
- \*CARBURETOR – Check and adjust if necessary.
- \*BELT CONVERTER – Check operation.
- POLYURETHANE FOAM AIR FILTER ELEMENT – Clean and oil. Service more frequently if operated in dusty areas.
- BRAKE CONTROL LINKAGE – Check linkage and adjust if necessary.
- TIRES – Inspect and check air pressure or circumference.
- ALL NUTS, BOLTS, AND OTHER FASTENERS – Check security and tighten if necessary.

#### REGULAR SERVICE PERIOD EVERY 3 MONTHS OF OPERATION

- SPARK PLUG – Clean and adjust gap, or replace if necessary.
- \*CONTACT POINTS AND IGNITION TIMING – Clean, check, and adjust or replace if necessary.
- POLYURETHANE FOAM AIR FILTER ELEMENT – Clean and oil. Service more frequently if operated in dusty areas.
- \*CARBURETOR – Check and adjust if necessary.
- \*BELT CONVERTER – Check operation.
- BRAKE CONTROL LINKAGE – Check linkage and adjust if necessary.
- TIRES – Inspect and check air pressure or circumference.
- ALL NUTS, BOLTS, AND OTHER FASTENERS – Check security and tighten if necessary.
- \*REDUCTION GEAR CASE – Check oil level and oil leakage.

#### EVERY YEAR

- FUEL LINE – Check.
- STEERING SYSTEM – Check operation and adjust if necessary.
- \*BRAKE SHOES AND PADS – Inspect and replace if worn.
- SPARK ARRESTOR – Check for carbon build-up and clean if necessary.

**B. LUBRICATION POINT**

LUBRICATION POINT	LUBRICANT	INTERVAL
Reduction case	A.P.I. Service Classification SE SAE 10W - 40 or SAE 10W - 30	
Recoil Starter	Multipurpose Grease	Overhaul
Steering Shaft Bushings		Overhaul
Lever Shafts		As necessary
Front Arms		Overhaul
King-Pins		Overhaul
Front Hub Bearings		Overhaul
Seat Adjusters		As necessary
Parking Brake Lever		As necessary
Parking Brake Wire Guide		As necessary
Rear Brake Bearings		Overhaul
Disc Brake Ratchet		Overhaul
Disc Pads	Silicon Grease KS 62M	Overhaul
Tie-Rod Ball Joints	Texaco Molytex Grease 2	



## TECHNICAL DATA

### A. Standard Tolerances and Wear Limit

O.D. = Outside Diameter  
I.D. = Inside Diameter  
Unit : mm (in.)

SUBJECT OR ITEM		MEASUREMENT	STANDARD		WEAR LIMIT	
ENGINE	Engine	Cylinder I.D.	70.0 - 70.01	(2.7559 - 2.7563)	70.1	(2.7598)
		Piston O.D.	69.93 - 69.95	(2.7531 - 2.7539)	69.8	(2.7480)
		Piston pin hole I.D.	18.002 - 18.008	(0.7087 - 0.7090)	18.1	(0.7126)
		Piston pin O.D.	17.992 - 18.000	(0.7083 - 0.7087)	17.98	(0.7079)
		Piston ring side clearance	Top	0.045 - 0.075	(0.0018 - 0.0030)	0.09 (0.0035)
			2nd	0.025 - 0.055	(0.0010 - 0.0022)	0.07 (0.0028)
		Piston ring gap	Top	0.2 - 0.4	(0.0079 - 0.0157)	0.5 (0.0197)
			2nd	0.2 - 0.4	(0.0079 - 0.0157)	0.5 (0.0197)
		Connecting rod small end I.D.	21.997 - 22.009	(0.866 - 0.8665)		
		Connecting rod big end axial clearance	0.2 - 0.4	(0.0079 - 0.0157)	0.6	(0.0236)
		Connecting rod big end radial clearance	0.010 - 0.022	(0.0001 - 0.0009)	0.03	(0.0012)
		Crankshaft runout	0.04 max.	(0.00157)		
	Carburetor	Float height	20	(0.79)		
	Electrical	3-point gap	6/3,000 rpm	(0.24)/3,000 rpm	5/500 rpm (0.20)/500 rpm	
		Point gap	0.3 - 0.4	(0.012 - 0.016)		
		Plug gap	0.7 - 0.8	(0.028 - 0.32)		
FRAME	Steering	Throttle lever free play	5	(0.20)	2 - 10	(0.08 - 0.39)
		Throttle lever full travel	36	(0.06)	31 - 41	(1.22 - 1.61)
		Steering wheel force			0.5 - 1.1 Kg	(1.10 - 24.26 lb.)
		Shaft O.D.	17.957 - 18.0	(0.7070 - 0.7087)	17.7	(0.6968)
		Column bushing I.D.	17.9 - 18.3	(0.7047 - 0.7205)	18.5	(0.7283)
		Shaft bushing I.D.	18.06 - 18.081	(0.71102 - 0.7118)	18.2	(0.7165)
	Front suspension	Shock absorber spring free length	229.4	(9.03)	205	(8.07)
		Front arm I.D.:				
		Pivot pipe	42.58 - 42.62	(1.6764 - 1.6780)	42.8	(1.6850)
		King-pin	14.03 - 14.06	(0.5524 - 0.5535)	14.15	(0.5570)
		Toe-in	8	(0.315)	0 - 13	(0 - 0.51)
		Pivot pipe O.D.	42.47 - 42.50	(1.6721 - 1.6732)	42.3	(1.6653)
		King-pin O.D.	13.97 - 13.98	(0.5500 - 0.5504)	13.9	(0.5472)
	Rear wheel axle	Rear wheel axle bend			3.0	(0.1181)
	Brake	Brake lever free play	3	(0.12)	1 - 5	(0.04 - 0.20)
		Brake lever full travel	70	(2.76)	62 - 78	(2.44 - 3.07)
		Brake lever remaining effective travel			above 23 (above 0.90)	
		Parking brake			1 - 5 notches	
		Disc runout			0.3	(0.0118)
		Disc thickness	3.2	(0.1260)	3.0	(0.1181)
		Brake lining thickness	4.25	(0.1673)	1.5	(0.0591)
		Brake drum I.D.	139.9 - 140.1	(5.5079 - 5.5157)	140.6	(5.5354)

**B. Torque Specifications**

SUBJECT	ITEM	DESCRIPTION	THREAD DIA.	TORQUE	
				Kg – cm	lb – ft
ENGINE	Engine	AC Generator rotor	M12	450 – 500	33 – 36
		Cylinder head flanged nut	M6	100 – 130	7 – 9
		Cylinder head special nut	M8	200 – 250	15 – 18
		Spark plug	M14	150 – 200	11 – 15
		Cylinder head sealing bolt	M14	200 – 300	15 – 22
		Crankcase retaining bolt	M6	80 – 120	6 – 9
		Recoil starter rope guide nut	M14	30 – 40	2 – 3
		Engine hanger bolt	M10	350 – 430	25 – 31
	Carburetor	Insulator band	M5	50 – 70	4 – 5
	Muffler	Retaining nut	M8	150 – 200	11 – 15
		Retaining bolt	M8	190 – 250	14 – 18
	Reduction unit	Reduction cover retaining bolt	M8	190 – 250	14 – 18
		Oil check bolt	M8	70 – 120	5 – 9
		Ramp plate mounting screw		110 – 140	8 – 10
		Roller arm retaining bolt		70 – 100	5 – 7
		Driven pulley retaining bolt	M8	230 – 310	17 – 22
		Drive pulley retaining bolt	M12	500 – 700	35 – 50
FRAME	Steering and front suspension	Lever to shaft	M5	40 – 80	3 – 6
		Lever shaft to arm	M5	40 – 80	3 – 6
		Steering wheel and shaft	M12	350 – 450	25 – 33
		Ball joint and front arm	M10	350 – 430	25 – 31
		Tie-rod lock nut	M10	350 – 430	25 – 31
		Front shock absorber (Top)	M12	400 – 500	29 – 36
		Front shock absorber and front arm (Bottom)	M10	350 – 430	25 – 31
		King-pin lock nut	M8	150 – 200	11 – 15
		Front hub lock nut	M8	190 – 250	14 – 18
		Front rim	M8	190 – 250	14 – 18
		Front tire	M8	190 – 250	14 – 18
		Front hub	M14	600 – 800	43 – 58
		Front arm stopper	M8	190 – 250	14 – 18
	Power Train and brake	Rear rim	M8	190 – 250	14 – 18
		Rear hub lock nut	M8	190 – 250	14 – 18
		Rear hub	M14	600 – 800	43 – 58
		Rear brake bearing holder	M8	190 – 250	14 – 18
		Rear tire	M8	190 – 250	14 – 18
		Brake arm	M6	70 – 120	5 – 9
		Brake caliper pin	M8	190 – 250	14 – 18
		Parking brake	M8	190 – 250	14 – 18
	Fuel system	Fuel tank to guard pipe	M6	70 – 120	5 – 9
		Fuel valve	M6	80 – 100	6 – 7
		Fuel pump	M6	70 – 120	5 – 9






SUBJECT	ITEM	DESCRIPTION	THREAD DIA.	TORQUE	
				Kg – cm	lb – ft
FRAME	Frame Parts	Guard pipe to roll bar	M8	190 – 250	14 – 18
		Guard pipe:			
		Front	M8	190 – 250	14 – 18
		Rear	M8	190 – 250	14 – 18
		Roll bar to rear roll bar	M8	190 – 250	14 – 18
		Rear roll bar	M8	190 – 250	14 – 18
		Rear roll bar to guard pipe	M8	190 – 250	14 – 18
		Front bumper	M8	190 – 250	14 – 18
		Seat back to adjuster	M8	150 – 200	11 – 15
		Adjuster cover	M6	70 – 120	5 – 9
		Seat cushion stay	M8	190 – 250	14 – 18
		Seat cushion	M6	70 – 120	5 – 9
		Adjuster	M8	190 – 250	14 – 18
		Seat cushion to stay	M6	70 – 120	5 – 9
		Seat belt		300 – 350	22 – 25
		Drive belt cover	M6	70 – 120	5 – 9
		Pulley cover	M6	70 – 120	5 – 9
	Engine mounting	Engine rubber mounting	M6	70 – 120	5 – 9
		Engine rubber mounting to engine bed	M10	350 – 430	25 – 31






# GENERAL DATA


## A. Overall Vehicle Dimensions




UPPER VIEW



SIDE VIEW



FRONT VIEW



REAR VIEW

## B. General Specifications

DESCRIPTION		SPECIFICATION
Overall length		2,095 mm (82.48 in.)
Overall width		1,230 mm (48.43 in.)
Overall height		1,525 mm (60.04 in.)
Wheel base		1,435 mm (56.50 in.)
Track	front	930 mm (36.61 in.)
	rear	950 mm (37.40 in.)
Ground clearance		140 mm ( 5.51 in.)
Min. turning circle radius		4.3 m (17.39 ft.)
WEIGHT	Dry weight distribution	Front 65 Kg (143.4 lbs)
		Rear 115 Kg (253.5 lbs)
	Max. laden weight	265 Kg (584.3 lbs)
EFFICIENCY	Max. stabilized inclination, right/left	53°
	Max. climbing angle	35°
	Stopping distance	20 m (at 50 Km/h) 32.8 ft. (at 31.25 mph)
ENGINE	MODEL	FL 250E
	TYPE	Air-cooled, 2-stroke
	Cylinder arrangement	Single-cylinder 15° inclined from vertical
	Bore and Stroke	70.0 x 64.4 mm (2.756 x 2.535 in.)
	Displacement	248 cc (15.1 cu. in.)
	Compression Ratio	6.6
	Compression Pressure	9 Kg/cm <sup>2</sup> /800 rpm
	Fuel	Gasoline 20 : oil 1 (mixed)
	Ignition timing	5° BTDC
	Port timing	Intake — Open 80° BTDC
		Close 80° ATDC
		Exhaust — Open 87° BBDC
		Close 87° ABDC
		Scavenge — Open 60° BBDC
		Close 60° ABDC



DESCRIPTION			SPECIFICATION
ENGINE	Idle speed		1,500 rpm
	Valve mechanism		Piston valve type
	Lubrication system		Forced and wet sump
	Carburetor type		PW type
	Choke system		Starter valve system
	Air cleaner type		Semi-dry type
	Fuel pump type		Diaphragm type
	Belt converter		SALSBURY'S Torque sensitive belt converter
	Engine dry weight		22 Kg (48.51 lbs.)
CAPACITIES	Fuel tank		12 lit. (0.317 US gal., 0.264 Imp. gal.)
	Reduction unit		0.5 lit. (1.057 US pt., 0.88 Imp. pt.)
ELECTRICAL	Starting system		Recoil starter
	Stopping system		Ground switch
	Ignition system		Flywheel magneto
	Generator		AC Generator
	Spark plug		NGK B7ES
	Spark plug gap		0.7 – 0.8 mm (0.0276 – 0.0315 in.)
STEERING	Max. turning angle, right/left		45°
	Arm ratio (Knuckle arm length/center arm length)		1.7
	Steering angle	inside	28°
		outside	20°
SUSPENSION	Front		Trailing arm type Coil spring
	Rear		Wheel axial type
	Front shock absorber		Coil spring type
ALIGNMENT	Front	Side slip (ridden)	0 mm (0 in.)
		Toe-in	8 mm (0.315 in.)
		Camber	1°
		Caster	8°
		King pin angle	8°
		Side off set	9 mm (0.354 in.)
		Caster trail	50 mm (1.969 in.)
	Rear	Side slip (ridden)	0 mm (0 in.)
		Toe-in	0 mm (0 in.)
		Camber	0°



DESCRIPTION		SPECIFICATION
BRAKES	Main brake	Self-adjusting cable actuated disc
	Parking brake	Cable actuated leading-trailing shoe and drum
	Disc effective diameter	220 mm (8.661 in.)
	Parking brake drum diameter	140 mm (5.512 in.)
TIRES	Rim, width x diameter,	front 140 x 203 mm (5.51 x 8 in.)
		rear 210 x 203 mm (8.27 x 8 in.)
	Tire, O.D. x width x I.D.,	front 508 x 178 – 203 mm (20 x 7 – 8 in.) (2 ply)
		rear 559 x 280 – 203 mm (22 x 11 – 8 in.) (0 ply)
	Pressure	front 0.35 Kg/cm <sup>2</sup> (5.0 psi.)
		rear 0.21 Kg/cm <sup>2</sup> (3.0 psi.)
LIGHTS	Headlight	6 V – 35 W




## ENGINE REMOVAL/ INSTALLATION

- Before removing, make sure to perform the following operations;

- Remove the seat back.
- Set the parking brake.
- Drain the fuel line and carburetor.

- Remove in ①, ②, ③ . . . . . sequence.









### A. AIR CLEANER & MUFFLER




Fig. 1 AIR CLEANER DISASSEMBLY/REASSEMBLY






Fig. 2 MUFFLER DISASSEMBLY/REASSEMBLY



- ① Wash in clean stoddard solvent.
- ② Dry thoroughly.
- ③ Soak in clean gear oil (SAE 80 – 90) until saturated.
- ④ Squeeze out excess oil.

Fig. 3 Air Cleaner Element Cleaning





- ① Use propane torch to burn off oil from carbon deposits.

**WARNING**

Do not use torch near flammable material.

**CAUTION**

Do not use oxyacetylene torch to burn off oil.



- ② Hold muffler in vertical position and tap it on a wood block to shake out carbon deposits.



- ③ Clean spark arrester with wire brush.

Fig. 4 Muffler and Spark Arrester Decarbonizing



### B. CARBURETOR

**NOTE**

1. Before disassembly, clean around carburetor and be sure to drain.
2. Before assembly, clean carburetor and related parts using compressed air.





Fig. 1 Carburetor Disassembly/Reassembly


**CAUTION**

Carefully handle jets, needles and other small parts.

**NOTE**

Blow jets to check for clogging.


Fig. 2 Float Chamber Disassembly/Reassembly



- ① Place in upright position
- ② When the float arm tang just closes the float valve, without compressing the spring loaded plunger, measure the float height.


Standard : 20 mm (0.79 in.)

Fig. 3 Float Height Inspection




- Carefully bend the float arm tang to adjust to proper float level.

Fig. 4 Float Height Adjustment



THROTTLE STOP SCREW



AIR SCREW

### CAUTION

- Before adjusting, perform the following steps.
    - Attach a suitable tachometer.
    - Set the parking brake.
    - Check to see that the ignition system and engine compression are in good condition.
  - Do not compensate for other faults by carburetor adjustment.
- ① Start the engine and allow to idle until operating temperature is reached.
  - ② Adjust the throttle stop screw at approx. 1,500 rpm.
  - ③ Turn the air screw clockwise until the engine begins to miss or decrease in speed.
  - ④ Turn the air screw counterclockwise until the engine begins to miss or decrease in speed.
  - ⑤ Set the air screw exactly between these two extreme positions. The correct setting will be found to be approximately 2 turns open from the fully closed position.
  - ⑥ If the idle speed changes, readjust the throttle stop screw.

Specification : 1,500 rpm  $\pm$  150 rpm

Fig. 5 Idle Speed Adjustment



## C. RECOIL STARTER




Fig. 1 Recoil Starter Disassembly




**WARNING** Use gloves to assemble the recoil starter.


**NOTE**

Turn the case to wind the spring in.

- ① Set the return spring inside the case.




- ② Wind the starter rope around the pulley.




- ③ Take the rope end out of the slot.


- ④ Set the pulley inside the case engaging the spring end and projection on the pulley as shown on page 8 - 6.



- ⑤ Wind pulley 2½ turns.



- ⑥ Knot rope end as shown on page 8 - 6.



- ⑦ After assembling, check that the starter works properly.

Fig. 2 Recoil Starter Reassembly



**D. GENERATOR & IGNITION SYSTEM**

Fig. 1 Generator/Ignition System Disassembly/Reassembly

**CLUTCH OUTER HOLDER**  
(Tool No. 07923 - 0010000)**FLYWHEEL PULLER**  
(Tool No. 07933 - 0010000)


Fig. 2 Rotor Removal





- Connect wires in accordance with instructions provided with the service tester.
- Replace if no continuity.


Fig. 3 Ignition Coil Continuity Test



- ① Connect wires in accordance with instructions provided with the service tester.
- ② Measure stable max. distance jumping across 3-point spark gap.

Standard	: 6 mm (0.24 in.) at 3,000 rpm
Service limit	: 5 mm (0.20 in.) at 500 rpm



NORMAL



### NOTE

Connect high tension cable to tester in-reverse direction.

Fig. 4 Ignition Coil Performance Test




- Measure plug gap.

Standard : 0.7 – 0.8 mm (0.028 – 0.032 in.)
---



- Clean spark plug with plug cleaner or wire brush.

Fig. 5 Spark Plug Inspection/Cleaning




- Check for breakage.

Fig. 6 Stator Cable Continuity Test



- Check for damage or burning.
- Polish with emery cloth or point file if burned, pitted or worn.


Fig. 7 Contact Breaker Inspection



- Replace if beyond specification.


Standard	: 0.3 – 0.4 mm (0.012 – 0.016 in.)
Service limit	: 0.2 – 0.6 mm (0.008 – 0.024 in.)

Fig. 8 Point Gap Inspection



- ① Remove the recoil starter and the starter pulley.
- ② Connect the black lead to the test light lead and the other test light lead to the positive battery terminal, and ground the negative terminal.
- ③ Turning the rotor clockwise, the light should become dim when the "F" mark and the matching mark align.
- ④ To adjust, slightly loosen screw (A), move rotating plate in either direction using a standard screwdriver inserted in the cutout (B) and retighten screw (A) where the test light starts to dim.

Fig. 9 Ignition Timing Static Adjustment



- ① Remove the recoil starter.
- ② Connect the wires in accordance with the instructions provided with the service tester.
- ③ Start the engine by using a rope wound around the starter pulley. Check the ignition timing at idle.

Fig. 10 Ignition Timing Dynamic Inspection



## E. CYLINDER &amp; PISTON

## NOTE:

Before disassembly, remove dust, dirt and mud from around the engine.




Fig. 1 Cylinder/Piston Disassembly/Reassembly





Fig. 2 Wrist Pin Clip Removal

### NOTE

Place a rag under the piston to keep the wrist pin clip from dropping into the crankcase.




- Remove from direction opposite of gap.



### CAUTION

Install marked side up.  
Be careful to use the proper rings.  
(Note sectional view.)



Fig. 3 Piston Ring Disassembly/Reassembly



### CAUTION


Install the piston with the dowel pins facing toward the intake port.

Fig. 4 Piston Installation




- Decarbonize with a scraper, screwdriver or wire brush taking care not to score or scratch.

Fig. 5 Cylinder Head/Exhaust Port Decarbonizing




Standard	: 69.93 – 69.95 mm (2.7531 – 2.7539 in.)
Service limit	: 69.8 mm (2.7480 in.)

Fig. 6 Piston O.D. Inspection



Standard	: 70.0 – 70.01 mm (2.7559 – 2.7563 in.)
Service limit	: 70.1 mm (2.7598 in.)


Fig. 7 Cylinder I.D. Inspection



Check for carbon deposits.


Check for scores, cracks or carbon deposits.

Fig. 8 Piston Inspection




Standard	Top	0.2 – 0.4 mm (0.0079 – 0.0157 in.)
	2nd	0.2 – 0.4 mm (0.0079 – 0.0157 in.)
Service limit	Top	0.5 mm (0.0197 in.)
	2nd	0.5 mm (0.0197 in.)

Fig. 9 Piston Ring Gap Inspection



Standard	Top	0.045 – 0.075 mm (0.0018 – 0.0030 in.)
	2nd	0.025 – 0.050 mm (0.0010 – 0.0022 in.)
Service limit	Top	0.09 mm (0.0035 in.)
	2nd	0.07 mm (0.0028 in.)

Fig. 10 Piston Ring Side Clearance Inspection



Standard	:	17.992 – 18.000 mm (0.7083 – 0.7087 in.)
Service limit	:	17.98 mm (0.7079 in.)

Fig. 11 Wrist Pin O.D. Inspection





Fig. 12 Wrist Pin Hole I.D. Inspection

Standard	: 18.002 – 18.008 mm (0.7087 – 0.7090 in.)
Service limit	: 18.1 mm (0.7126 in.)




- Since the wrist pin and connecting rod are selective-fitted, the proper needle bearing should be selected in accordance with the following table.

BEARING SELECTION TABLE

Con-rod small end I.D. \ Wrist pin dia.	With notch	Without notch
1 notch	Red	—
2 notches	Blue	Red
3 notches	White	Blue

Fig. 13 Con-Rod Small End Bearing Selection

**NOTE**

Before checking, make sure that the engine is warmed up and the throttle is fully opened.

- Low compression is usually caused by one of the following;
  - Defective or sticking piston ring.
  - A blown cylinder head gasket.
- Unusually high compression pressure is due to excessive carbon deposits in the combustion chamber or on the piston head.
- The engine must be disassembled for complete inspection or repair if the compression exceeds the limit.

Specified pressure:  
9 Kg/cm<sup>2</sup> (129 psi.)/800 rpm

Fig. 14 Cylinder Compression Inspection





### F. CRANKSHAFT & CRANKCASE







Fig. 1 Crankshaft/Crankcase Disassembly/Reassembly

**S. TOOL****CASE PULLER**  
(Tool No. 07933 – 9500000)

- Used for R/L CRANKCASE pulling.

**S. TOOL****BEARING DRIVER**  
(Tool No. 07946 – 3330300)


Fig. 2 Crankshaft/Crankcase Disassembly/Reassembly



- Measure at two points in directions as shown with arrows.


Standard	: 0.010 – 0.022 mm (0.0004 – 0.0009 in.)
Service limit	: 0.03 mm (0.0012 in.)

Fig. 3 Connecting Rod Large End Radial Clearance Inspection




Standard	: 0.2 – 0.4 mm (0.0079 – 0.0157 in.)
Service limit	: 0.6 mm (0.0236 in.)

Fig. 4 Connecting Rod Large End Axial Clearance Inspection




Standard : Less than 0.04 mm (0.00157 in.)

Fig. 5 Crankshaft Runout Inspection



Standard : 21.997 – 22.009 mm (0.8660 – 0.8665 in.)

Fig. 6 Connecting Rod Small End I.D. Inspection




- Since the connecting rod large end and crank pin are selective-fitted, proper needle bearing should be replaced in accordance with the following table.

BEARING SELECTION TABLE

Con-rod large end I.D.	Crank pin O.D.		
	2 notches	1 notch	Without notch
Without notch	Red		
1 notch	Blue	Red	
2 notches	White	Blue	Red
3 notches		White	Blue

Fig. 7 Con-Rod Large End Bearing Selection



**Fig. 8 Ball Bearing Play Inspection**




## G. REDUCTION UNIT

**NOTE**

Refer to FRAME section to remove rear wheels, rear axle, brake drum and disc brake system.

- Before disassembly, drain reduction case.



: Shaded parts

Fig. 1 Reduction Unit Disassembly/Reassembly



### NOTE

To assemble, follow ①, ②, ③ . . . . . in this sequence.

- After assembly, be sure that the chain rotates smoothly.





Fig. 2 Reduction Unit Reassembly




### CAUTION

Install bearing equally by driving outer edge.

S. TOOL


BEARING DRIVER  
(Tool No. 07945 - 3330300)

Fig. 3 Ball Bearing Assembly



- Replace if excessively worn.

Fig. 4 Ball Bearing Play Inspection



Check the drive chain for wear or other defects if the sprockets are abnormal.

Fig. 5 Driven Sprocket Inspection





### H. BELT CONVERTER

- For more detailed instructions, refer to SALSURY's shop manual.






Fig. 1 Belt Converter Disassembly / Reassembly



- ① Remove the mounting bolt, lock washer, flat washer, and safety cup.




- ② Apply grease to threads of the clutch puller tool and insert it fully into the drive pulley bore and apply torque with 1-1/4 inch wrench, while holding the drive pulley with the special spanner. It may be necessary to inflict a slight impact on the head of the puller tool with a hammer to unseat the taper and remove the drive pulley.

Fig. 2 DRIVE PULLEY DISMOUNT





S. TOOL

TAPER PLUG  
(Salsbury #703463)



S. TOOL

SPIDER  
INSTALLATION  
CUP  
(Salsbury #704229)



- ① Using a plastic mallet, insert the taper plug into the taper of the drive pulley with a slight impact and place the taper plug flats in a bench vise.
- ② Bend the tabs of the lock plate away from the heads of the three 1/4-20 self-tapping ramp plate mounting screws with a chisel.
- ③ Remove the three ramp plate mounting screws with a 3/8 inch wrench. Remove the lock plate and the three flat washers.
- ④ Remove the snap ring from the hub with snap ring pliers. If the snap ring is tight, place the spider installation cup over the hub and onto the snap ring and hit the ring sharply with a hammer until the snap ring loosens.
- ⑤ Remove the snap ring and the ramp plate.
- ⑥ Disengage the six roller arm return springs with a flat blade screwdriver.
- ⑦ Bend the lock plate tabs away from the heads of the three 1/4-20 arm clamp mounting bolts with a chisel.
- ⑧ Remove the arm clamp mounting bolts with a 7/16 inch or 11 mm open end wrench.
- ⑨ Remove the lock tabs, the three arm pivot pin clamps and the three roller arms/springs/pins and bushing subassemblies. The drive pulley is now fully disassembled for normal servicing.

Fig. 3 DRIVE PULLEY DISASSEMBLY




Spider removal for servicing the fixed face and hub, movable face assembly or the spider can be performed as per detailed instructions. However, it is impractical in most cases, i.e. if the movable face is worn, dictating replacement, the fixed face and hub will probably be in the same condition. It is usually less expensive to replace the entire drive pulley when the faces require replacement.

**S. TOOL**

SCREW (1/4-20 x 2-3/4)  
(Salsbury #900403)

STEP PLUG  
(Salsbury #704232)

PULLER PLATE  
(Salsbury #704233)



**Disassembly:**

- ① Place the stepped thrust block into the threaded end of the drive hub, place the puller assembly into position (cupped side down) and run the three (1/4-20) puller bolts fully into the threaded holes in the spider with a 7/16 inch or 11 mm open end wrench.
- ② Grease the puller bolts and tighten them in a clockwise direction with a 1-1/8 wrench until the spider is free from the hub.

**S. TOOL**

SCREW (1/2-20 x 5-1/2)  
(Salsbury #901836)

SPIDER  
INSTALLATION  
CUP


**Reassembly:**


If the spider has been removed for servicing and is to be reused, replace the movable face on the hub, place the spider in position (on the hub) and place the spider installation cup over the spider, cupped side down.

Thread the 1/2-20 x 5-1/2 inch bolt through the flat washer and the cup into the threaded taper plug. Continue tightening with a 3/4 inch open end wrench until the cup bottoms out on the end of the hub. Be sure that, during this pressing operation, the spider pins are aligned with the mating bearing in the movable face. A constant alignment of pins to bearings can be achieved by raising the movable face up against the spider and placing a small wad of paper between the fixed and the movable faces.


**Hydraulic Press Installation**

Install the movable face on the hub, lay the spider in position and place this assembly on a flat plate under hydraulic ram. Do not use the tapered plug. Center spider installation cup over the spider and carefully apply hydraulic pressure on the cup until it bottoms out on the end of the hub, while maintaining spider pin/bearing alignment.

Fig. 4 SPIDER DISASSEMBLY/REASSEMBLY




- ① Install the tapered plug into the tapered bore of the drive pulley and place the drive pulley assembly in a vise. Install the roller arms, springs, pins and bushing subassemblies into the appropriate nests in the movable face assembly.
- ② Install the roller arm pivot pin clamps, lock plates and 1/4-20 bolts.
- ③ Tighten the 1/4-20 bolts to 110-140 Kg-cm (8-10 lb-ft) and bend the lock tabs against the bolt heads.




S. TOOL

SPRING SEATING TOOL  
(Salsbury #703446)



- ④ Engage the six roller arm return springs with the Spring Installation Tool, while the movable face is positioned against the spider. Placing a wad of paper between the fixed and the movable faces may be helpful in maintaining this position.
- ⑤ Install the ramp plate and the snap ring (recommended snap ring application is flattest surface up against the load side of the groove), noting that the three holes in the ramp plate are aligned with the holes in the spider.
- ⑥ Install the flat washers, the lock plate and the three 1/4-20 self tapping bolts. Torque the bolts to 110-140 Kg-cm (8-10 lb-ft) and bend the lock tabs against the bolt heads.
- ⑦ Mount the drive pulley on the crankshaft. Be certain that both tapers are clean and dry.

Fig. 5 DRIVE PULLEY REASSEMBLY



① Disengage the torsion/compression spring end from the boss on the underside of the cam with a flat blade screwdriver. For total spring unloading repeat the preceding to disengage the spring from the second boss.

② Place the head of the special screw (1/2-20) in a bench vise. Place the driven pulley on the special screw. Place the puller plate, flat washer and 1/2-20 nut on the special screw over the driven pulley.

③ Tighten 1/2-20 nut until the puller plate bottoms out on the end of the driven pulley hub. Install the cam retainer on the ends of the movable face casting and the cam.

④ Remove the 1/2-20 nut, flat washer and puller plate.


⑤ Remove the snap ring. Check for burrs at the snap ring groove. If present, carefully remove them with a flat file.

⑥ Replace the puller plate, flat washer and 1/2-20 nut (finger tight).

⑦ Remove the cam retainer. Loosen the 1/2-20 nut slowly until the cam is free of the hub. If the cam does not free itself, refer to paragraph ⑤.

⑧ Remove the Morton Key with diagonal pliers. Now all parts are loose and the movable face can be removed.

Fig. 6 DRIVEN PULLEY DISASSEMBLY/REASSEMBLY



- ① Place the movable face over the fixed face hub. Install the Morton Key.
- ② Place the head of the special 1/2-20 bolt in a bench vise. Place the fixed and the movable face assembly on the screw (fixed face down).
- ③ Hook the spring end over any one of the round bosses on the internal side of the cam. While holding the cam and spring, attach the other end of the spring to any one of the three spring anchor points in the movable face. Rotate the fixed face and hub until the key and the keyway are aligned.  
Place the puller plate, flat washer and 1/2-20 nut over the cam and depress the cam on the hub until it engages with the key, thus allowing the movable face to rotate without cam contact.
- ④ Rotate the movable face counterclockwise to achieve a full 180° spring preload and hold it in this position.
- ⑤ Continue depressing the cam until the puller plate has bottomed out on the end of the hub. Securely apply the cam retainer over the ends of the movable face casting and the cam.
- ⑥ Remove the 1/2-20 nut, flat washer and puller plate.
- ⑦ Install the snap ring (flattest surface up against the load side of the groove).
- ⑧ Remove the cam retainer. Be certain that the cam is against the snap ring.
- ⑨ When remounting, no special procedure is required. Do not forget the key.


**NOTE** Keep the pulleys clean.  
Never apply grease or oil.

**NOTE** When using the clutch puller tool or special screw (#602114), grease should be applied to the threads for ease of use and to extend their service life.


Fig. 7 DRIVEN PULLEY DISASSEMBLY/REASSEMBLY

**WARNING**

Before removing, set parking brake.



- ① Turn the movable face 90° counterclockwise, pull it toward you to loosen the drive belt and push the loosened belt down toward the hub center.



- ② While holding the movable face on described in step ①, take off the loosened belt from lower side with your other hand.
- ③ After removing the belt at the driven pulley side, remove the belt completely from the drive pulley.
- ④ When reassembling, after installing on the drive pulley, install the belt on the driven pulley from the upper side.

**CAUTION**

Replace the drive belt if it is excessively worn as shown below.






Fig. 8 Drive Belt Removal & Replacement





- At low speeds, the V-belt position of the drive pulley maintains a smaller diameter which with a corresponding larger diameter on the driven pulley, creates a "low gear" ratio.

- As speed increases, centrifugally actuated roller weights follow the contour of a bowl-shaped plate, closing the drive pulley sheaves and creating a "high gear" ratio (note the position of the cam actuator).



- If the load is increased (such as climbing a hill) after the vehicle is up to speed, the cam actuator on the driven pulley takes over and automatically "down-shifts" without loss of engine speed. Then, the engine remains at power range for all but the most severe loads, at which time it will shift into peak torque range.

Fig. 9 How Salsbury Belt Converters Work





## FRAME

### A. Steering




Fig. 1 Steering Wheel and Column Disassembly/Reassembly



- Adjustment, Fig. 4





Fig. 2 Steering Shaft Installation








Fig. 3 Lever and Shaft Installation



LEVER SIDE



CARBURETOR SIDE



### Lever Free Play

- Adjust the lever with the adjusting bolt.


Service limit : 2 – 10 mm (0.08 – 0.39 in.)

### Lever Full Travel

- ① Measure full travel as shown above.
- ② To adjust, remove lever and adjust position as required. Then install the lever. See Fig. 3.


Service limit 31 – 41 mm (1.22 – 1.61 in.)

Fig. 4 Throttle Lever Adjustment



Service limit : 17.7 mm (0.6968 in.)

Fig. 5 Steering Shaft O.D.




SPRING GAUGE

- ① Raise the front wheels off the ground.
- ② Turn the steering wheel with a spring gauge and note the reading.
- ③ If the reading exceeds the service limit, inspect the steering shaft and the front hub.

Service limit : 0.5 – 1.1 Kg (1.10 – 24.26 lb)

Fig. 7 Steering Wheel Force Check



STEERING COLUMN BUSHING

Service limit : 18.5 mm (0.7283 in.)

STEERING SHAFT BUSHING

Service limit : 18.2 mm (0.7165 in.)

Fig. 6 Steering Column I.D.



### B. Front Suspension




Fig. 1 Front Suspension Removal/Installation




Fig. 2 Spring Pin Removal




Fig. 3 Front Hub Disassembly





Fig. 4 Front Shock Absorber Disassembly








Fig. 5 Knuckle Installation




Fig. 6 Front Hub Bearing and Oil Seal Installation






Fig. 7 Tie-Rod Installation


**FREE LENGTH**

Standard	: 229.4 mm (9.03 in.)
Service limit	: 205 mm (8.07 in.)

Fig. 8 Shock Absorber Spring Free Length



**PIVOT PIPE**

Standard	: 42.58 – 42.62 mm (1.6764 – 1.6780 in.)
Service limit	: 42.8 mm ( 1.6850 in.)

**KING-PIN**


Standard	: 14.03 – 14.06 mm (0.5524 – 0.5535 in.)
Service limit	: 14.15 mm ( 0.5570 in.)

Fig. 9 Front Arm I.D.



Standard	:	42.47 – 42.50 mm (1.6721 – 1.6732 in.)
Service limit	:	42.3 mm ( 1.6653 in.)


Fig. 10 Pivot Pipe O.D.




Standard	:	13.97 – 13.98 mm (0.5500 – 0.5504 in.)
Service limit	:	13.9 mm ( 0.5472 in.)

Fig. 11 King-Pin O.D.


- ① Place the vehicle on level ground with the front wheels in a straight ahead position.



- ② Mark the centers of the tires with chalk to indicate the center height of an axle.




- ③ Align the toe-in gauge with the marks on the tires as shown.  
 ④ Check the readings on the scales of the gauges.



• After tightening the lock nuts, make sure the ball joints can be operated properly by rotating the tie rod.

- ⑦ When the toe-in does not meet the specification, adjust it by changing each length of the tie rods equally while measuring the toe-in.

- ⑤ Slowly move the vehicle back and rotate the wheels 180° until the marks on the tires are aligned with the height of the gauge on the rear side.  
 ⑥ Measure the toe-in on the rear part of the tires at the same points.



Toe-in : B-A

TOE-IN

Service limit : 0 - 13 mm (0 - 0.51 in.)

Fig. 12 Toe-in Adjustment



### C. Rear Wheel Axle





Fig. 1 Rear Wheel Axle Removal/Installation



Service limit : 3.0 mm ( 0.1181 in.)

Fig. 2 Rear Wheel Axle Bend



## FRAME

### D. Wheel





Fig. 1 Wheel Disassembly/Reassembly



### NOTE

If it is hard to remove the bead or if rust has formed on the bead, apply a coat of lubricant to the periphery of the rim before removing the tire. When reassembling, wipe off oil from the tire and the rim using a cloth.





Fig. 2 Tire Disassembly



- ① Check tire tread for nails or other puncturing objects; chalk mark punctured area. Remove nails or puncturing objects.



- ② Remove dirt and roughen punctured area with sandpaper or wire brush. Clean area with gasoline.
- ③ Apply rubber cement around torn area and allow it to dry. Remove the lining from the patch and center it over the puncture. Press the patch against the puncture using a special roller.






Fig. 3 Cold-Patch Repair



- ① Remove nails or other puncturing objects.
- ② Insert a rubber plug through the eye in the inserting needle.
- ③ Center the needle on the plug and insert until the plug is all the way in the tire; twist the needle several times.




- ④ Pull the needle straight out so that the plug is about 10 mm (0.394 in.) above tread surface. Trim the plug 2 mm (0.079 in.) above the surface. Repeat the above procedure if the puncture is large.

**NOTE**

This method is for emergency purposes only.  
After driving repair injury with cold patch.


Fig. 4 Rubber-Plug Repair






- ① Position the tire on the rim half which has the valve.
- ② Press the O-ring into place in the groove in the rim.
- ③ Install the other rim half. Be sure to align the rim bolt holes.

Fig. 5 O-Ring Installation



FRONT TIRE



REAR TIRE




Recommended Pressure  
0.35 kg/cm<sup>2</sup> (5.0 Psi)  
Max. Pressure  
0.5 kg/cm<sup>2</sup> (7.0 Psi)  
Min. Pressure  
0.3 kg/cm<sup>2</sup> (4.5 Psi)  
Standard Tire Circumference  
1.57 m (61.8 in.)

Recommended Pressure  
0.21 kg/cm<sup>2</sup> (3.0 Psi)  
Standard Tire Circumference  
1.84 m (72.5 in.)  
Max. Circumference  
2.00 m (78.7 in.)  
Min. Circumference  
1.80 m (71.0 in.)



Fig. 6 Tire Inflation

**E. Brake****DISC BRAKE**

- Removal/Installation, Fig. 1 and 4.
- Inspection, Fig. 7.
- Adjustment, Fig. 6.

**BRAKE LEVER**

- Inspection, Fig. 9.
- Adjustment, Fig. 11.

**BRAKE DRUM**

- Removal/Installation, Fig. 3.
- Inspection, Fig. 8.
- Installation, Fig. 5.

**PARKING BRAKE**

- Removal/Installation, Fig. 2.
- Inspection/Adjustment, Fig. 10




Fig. 1 Disc and Caliper Disassembly/Reassembly





Fig. 2 Parking Brake Removal/Installation



**FRAME**



### Fig. 3 Rear Brake Removal/Installation




Fig. 4 Pad and Brake Arm Installation




Fig. 5 Rear Brake Bearing and Oil Seal Installation





Fig. 6 Brake Arm Adjustment

- Squeeze the brake lever about ten times so that the automatic adjuster can operate properly. At this time slightly squeeze the lever as in bleeding operation. The lever free play is now automatically adjusted. See Fig. 9.




### PADS

- Inspect for wear.  
Replace the pads as a set if they are worn to the red line on each pad.



### DISC

- Inspect the disc surface for scores, cracks.



Using a dial indicator mounted as shown, rotate the disc slowly and check the runout.

**Service limit : 0.3 mm (0.0118 in.)**

- Replace the disc if it is worn beyond the service limit.

Using a micrometer, measure the disc thickness at four points and 30 mm (1.18 in.) from the outer edge of the disc.

### DISC THICKNESS

Standard	: 3.2 mm (0.126 in.)
Service limit	: 3.0 mm (0.1181 in.)

- Replace the disc if its thickness is less than the service limit.





Fig. 7 Pad and Disc Inspection



- Inspect the brake lining for cracking, glazing, wear or contamination.

- Inspect the brake drum for scoring, cracks and concentricity.


VERNIER CALIPER



DRUM I.D.

BRAKE DRUM


Service limit : 140.6 mm (5.5354 in.)



LINING THICKNESS

Standard	: 4.25 mm (0.1673 in.)
Service limit	: 1.5 mm (0.0591 in.)

Fig. 8 Brake Drum and Lining Inspection

**Remaining Effective Lever Travel**

- Pull the lever until contact is felt. Measure distance as shown above.


Service limit : above 23 mm (above 0.90 in.)

- Pad-to-disc clearance is automatically adjusted.

BRAKE LEVER SIDE



DISC CALIPER SIDE

**Lever Free Play**

- ① Measure lever free play.

Service limit : 1 – 5 mm (0.04 – 0.20 in.)


- ② To adjust, loosen the lock nut of the brake lever and turn the adjusting bolt.

**NOTE**


If unable to get the correct free play adjustment described above, readjust the cable length at the disc caliper side in the same way.

Fig. 9 Remaining Brake Lever Effective Travel/Free Play Inspection





- ① Raise the rear wheels off the ground.
- ② Pull the parking brake lever up 1 – 5 notches so that the rear wheels do not turn.
- ③ Release the brake lever and check that the rear wheels do not drag when turned.
- ④ If proper operation of the parking brake is not achieved by steps ② and ③ move the brake arm serration only one notch to adjust.





- ⑤ If the proper adjustment cannot be obtained with the serration moving, inspect the BRAKE DRUM, BRAKE SHOES and replace if necessary.

### SPECIFICATIONS

1 – 5 notches. Brakes fully engaged.

Fig. 10 Parking Brake Lever Inspection/Adjustment



- ① Measure the distance as above when the lever is free.
- ② To adjust, remove the lever and reinstall so that the proper lever position is achieved.

Service limit : 62 – 78 mm (2.44 – 3.07 in.)

Fig. 11 Brake Lever Full Travel Adjustment



## F. Fuel System




Fig. 1 Fuel Tank Removal/Installation




Fig. 2 Fuel Pump Disassembly/Reassembly



### G. Frame Parts




Fig. 1 Front Body Removal/Installation




Fig. 2 Seat Back and Cushion Removal/Installation




Fig. 3 Rear Frame Parts Removal/Installation



## H. Headlight






Fig. 1 Headlight Removal/Installation

## VERTICAL ADJUSTMENT BOLTS



## HORIZONTAL ADJUSTMENT NUT

**WARNING**

Make sure that the parking brake is set to avoid forward motion.


Fig. 2 Headlight Adjustment



**HONDA**  
**FL 250**

10

# ELECTRICAL DIAGRAM







# SHOP MANUAL

## HONDA ODYSSEY FL250

### ADDENDUM

#### POSTING THE FL250 ADDENDUM

Follow these instructions so that your FL250 Shop Manual is in order when you need to refer to it:

Start at the front of your shop manual —

1. Remove the old cover. Replace it with the new cover (6295001).
2. Remove the old Table of Contents. Insert the new Table of Contents page (Date of Issue: Sep. 1979).

Move to the back of the shop manual —

1. Insert the 1980 addendum directly behind page 10-1.
2. The FL250 addendum posting is now complete. You may now discard this cover sheet.





---

## FOREWORD

This addendum describes major modifications to the Honda FL250 ODYSSEY starting with Frame No. TB04-2000001 and Engine No. TBOE-2000001.

---

## TABLE OF CONTENTS



### GENERAL DATA

A. Overall Vehicle Dimensions .....	11-2
B. General Specifications .....	11-3
FRAME .....	11-4
ELECTRICAL DIAGRAM .....	11-9




# GENERAL DATA


## A. Overall Vehicle Dimensions



REAR VIEW



SIDE VIEW



FRONT VIEW



### B. General Specifications

DESCRIPTION		SPECIFICATION	
Overall length		2,095 mm (82.48 in.)	
Overall width		1,230 mm (48.43 in.)	
Overall height		1,625 mm (63.98 in.)	
Wheel base		1,435 mm (56.50 in.)	
Track	front	930 mm (36.61 in.)	
	rear	950 mm (37.40 in.)	
Ground clearance		140 mm ( 5.51 in.)	
Min. turning circle radius		4.3 m (17.39 ft.)	
WEIGHT	Dry weight distribution	Front	66kg (145.53 lbs.) *66kg (145.53 lbs.)
		Rear	119kg (262.40 lbs.) *120kg (264.60 lbs.)
	Max. laden weight		270kg (595.35 lbs.) *271kg (597.56 lbs.)
EFFICIENCY	Max. stabilized inclination, right/left		53°
	Max. climbing angle		35°
	Stopping distance		20 m (at 50 Km/h)
			61.0 ft (at 31.25 mph)
ENGINE	MODEL		FL 250E
	TYPE		Air-cooled, 2-stroke
	Cylinder arrangement		Single-cylinder 15° inclined from vertical
	Bore and Stroke		70.0 x 64.4 mm (2.756 x 2.535 in.)
	Displacement		248 cc (15.1 cu. in.)
	Compression Ratio		6.6
	Compression Pressure		9 Kg/cm <sup>2</sup> /800 rpm
	Fuel		Gasoline 20 : oil 1 (mixed)
	Ignition timing		5° BTDC
	Port timing	Intake	Open 80° BTDC
			Close 80° ATDC
		Exhaust	Open 87° BBDC
			Close 87° ABDC
		Scavenge	Open 60° BBDC
			Close 60° ABDC

\*Canada Model



DESCRIPTION			SPECIFICATION
ENGINE	Idle speed		1,500 rpm
	Valve mechanism		Piston controlled
	Lubrication system		Forced
	Carburetor type		PW
	Choke system		Starter valve system
	Air cleaner type		Oiled
	Fuel pump type		Diaphragm
	Belt converter		SALSBURY'S Torque converter
	Engine dry weight		22 Kg (48.51 lbs.)
CAPACITIES	Fuel tank		12 lit. (3.17 US gal., 2.64 Imp. gal.)
	Reduction unit		0.5 lit. (1.057 US pt., 0.88 Imp. pt.)
ELECTRICAL	Starting system		Recoil starter
	Stopping system		Ground switch
	Ignition system		Flywheel magneto
	Generator		AC Generator
	Spark plug		NGK BR7ES DENSO W22ESR
	Spark plug gap		0.7 – 0.8 mm (0.028 – 0.032 in.)
STEERING	Max. turning angle, right/left		45°
	Arm ratio (Knuckle arm length/center arm length)		1.7
	Steering angle	inside	28°
		outside	20°
SUSPENSION	Front		Trailing arm type Coil spring
	Rear		Wheel axial type
	Front shock absorber		Coil spring type
ALIGNMENT	Front	Toe-in	8 mm (0.315 in.)
		Camber	1°
		Caster	8°
		King pin angle	8°
		Side off set	9 mm (0.354 in.)
		Caster trail	50 mm (1.969 in.)
	Rear	Side slip (ridden)	0 mm (0 in.)
		Toe-in	0 mm (0 in.)
		Camber	0°



DESCRIPTION		SPECIFICATION
BRAKES	Main brake	Self-adjusting cable actuated disc
	Parking brake	Cable actuated leading-trailing shoe and drum
	Disc effective diameter	220 mm (8.661 in.)
	Parking brake drum diameter	140 mm (5.512 in.)
TIRES	Rim, width x diameter,	front 140 x 203 mm (5.51 x 8 in.)
		rear 210 x 203 mm (8.27 x 8 in.)
	Tire, O.D. x width x I.D.,	front 508 x 178 - 203 mm (20 x 7 - 8 in.) (2 ply)
		rear 559 x 280 - 203 mm (22 x 11 - 8 in.) (0 ply)
	Pressure	front 0.35 Kg/cm <sup>2</sup> (5.0 psi.)
		rear 0.21 Kg/cm <sup>2</sup> (3.0 psi.)
LIGHTS	Headlight	12V-45W
	Taillight	12V-3W (Canada Model only)



# FRAME

## Headlight

## Headlight Removal/Installation






Fig. 1

## Headlight Adjustment



Set the parking brake, start the engine.  
 Turn headlight "ON".  
 Adjust the headlight beam as shown.


**WARNING**

To avoid forward movement, make sure the parking brake is set.

Fig. 2





### Taillight Removal/Installation Taillight (Canada Model only)




Fig. 3

### Seat

The new seat is equipped with a heat shield. The seat also has thicker padding and a covering that is flexible at low temperatures.

### Heat Shield Removal/Installation





Fig. 4

**Engine Mounts**

Rebound limiters have been added to the front engine mounts, and the engine protector has been enlarged for rebound limiter clearance.


ENGINE  
MOUNT  
REBOUND  
LIMITERS

**Rear Tire**

The rear tires now have two reinforcing ribs on the side walls for increased rigidity and greater resistance against chafing.



**A.C. Generator**

The A.C. Generator was changed from a 6V-35W to a new 12V-45W type. Accordingly the taillight (Canada model) was changed from 6V-3W to 12V-3W. The headlight was changed from 6V-35W to 12V-45W.





(Canada Model only)



(Canada Model only)



### **INTRODUCTION**

This addendum describes major modifications to the Honda FL250 ODYSSEY starting with Frame No. TB0400BC400001 and Engine No. TB04 E-2400001. Refer to the base shop manual and the 1980 Addendum for service procedures and data not included here.

ALL INFORMATION, ILLUSTRATIONS, DIRECTIONS AND SPECIFICATIONS INCLUDED IN THIS PUBLICATION ARE BASED ON THE LATEST PRODUCT INFORMATION AVAILABLE AT THE TIME OF APPROVAL FOR PRINTING. HONDA MOTOR CO., LTD. RESERVES THE RIGHT TO MAKE CHANGES AT ANY TIME WITHOUT NOTICE AND WITHOUT INCURRING ANY OBLIGATION WHATEVER.

NO PART OF THIS PUBLICATION MAY BE REPRODUCED WITHOUT WRITTEN PERMISSION

HONDA MOTOR CO., LTD.  
SERVICE PUBLICATIONS OFFICE




### **CONTENTS**

<b>GENERAL INFORMATION.....</b>	<b>12-1</b>
<b>Dimensions .....</b>	<b>12-1</b>
<b>Specifications .....</b>	<b>12-2</b>
<b>REMOVAL/INSTALLATION.....</b>	<b>12-3</b>
<b>INSPECTION .....</b>	<b>12-7</b>
<b>FRAME.....</b>	<b>12-9</b>
<b>WIRING DIAGRAM.....</b>	<b>12-12</b>




# GENERAL INFORMATION

## A. Dimensions



FRONT VIEW



REAR VIEW



## B. Specifications

DESCRIPTION		SPECIFICATION
Overall height		1,465 mm (57.7 in.)
Min. turning circle radius		4.3 m (14.11 ft.)
WEIGHT	Dry weight	192 Kg (423 lbs)
	Distribution                      Front	71.5 Kg (157.5 lbs)
	Rear	120.5 Kg (265.5 lbs)
ENGINE	Compression Ratio	6.6:1
	Lubrication system	Fuel-oil mix
	Air cleaner	Semi-dry type
ELECTRICAL	Ignition system	C.D.I.
	Spark plug	NGK BR8ES, DENSO W24ESR
LIGHTS	Headlight	12V-60W

# REMOVAL/ INSTALLATION

1981 ADDENDUM


**HONDA**  
**FL 250**


## ENGINE


To remove the engine from the frame first remove these parts:

seat back and harness  
 muffler  
 drive belt covers  
 engine mounting bolts  
 fuel lines

The air cleaner does not have to be removed.








## ENGINE REMOVAL

Remove the engine by lifting and turning it as shown.




# REMOVAL/ INSTALLATION

1981 ADDENDUM


**HONDA**  
**FL 250**


## AIR CLEANER





## GENERATOR AND IGNITION SYSTEM



## INSPECTION


1981 ADDENDUM

**HONDA  
FL 250****IGNITION COIL**

Check the resistances between the leads of the primary and secondary coils:

Primary coil:  $0.2-0.8\ \Omega$

Secondary coil:  $8-15\ \text{k}\ \Omega$

**EXCITER COIL**

Adjust the seat so that it is completely forward.

Disconnect the A.C. generator wire connectors from the main harness clipped to the right side of the frame (see page 12-13).

Use an electrical tester to check continuity between the wires as shown.


The excitor coil is normal if there is continuity between the black/red wire and ground.

**SPECIFIED RESISTANCE:  $245\ \Omega$**


**PULSE COIL**

Measure the resistance between the Blue/Yellow and Green wires.

**RESISTANCE:  $20-60\ \Omega$**

**LIGHTING COIL**

The lighting coil is good if there is continuity between the yellow wire and ground.






### IGNITION TIMING

#### NOTE

Capacitive discharge ignition timing is not adjustable. If timing is incorrect, test the CDI unit and the AC generator, and replace the faulty part.

1. Remove the recoil starter.
2. Wind a rope around the pulley and start the engine.
3. Check the timing using a strobe light. Timing is correct if the index mark aligns between the two advance marks at 1500 rpm.

**NEW**




### CDI UNIT

#### NOTE


- The CDI unit is fully transistorized.
- For accurate testing, it is necessary to use a specified electric tester. Use of an improper tester may give a false reading.
- Use SANWA ELECTRIC TESTER (P/N 7308-0020000) or KOWA ELECTRIC tester (TH-5H).

Replace the CDI unit if the readings are not within the limits shown in the table.




UPPER: SANWA (SP-10D) xk  $\Omega$   
LOWER: KOWA (TH-5H) X100  $\Omega$



(-)	(+)	BLUE/ YELLOW	BLACK/ YELLOW	BLACK/ RED	BLACK	GREEN
BLUE/ YELLOW			$\infty$	$\infty$	$\infty$	$\infty$
BLACK/ YELLOW		$\infty$		$\infty$	$\infty$	$\infty$
BLACK/ RED		$\infty$	$\infty$		0.5-10.0 5.0-100.0	$\infty$
BLACK		$\infty$	$\infty$	$\infty$		$\infty$
GREEN		$\infty$	$\infty$	0.5-10.0 5.0-100.0	1.0-30.0 10.0-300.0	





## REAR FRAME



**HEADLIGHT**






**HONDA**  
**FL 250**

1981 ADDENDUM

12

# WIRING DIAGRAM



B Black  
Br Brown  
G Green  
Bl Blue  
W White  
Y Yellow

ENGINE STOP SWITCH

	IG	E
OFF		
ON		
COLOR	B	G

LIGHTING SWITCH

	HL-L	CO	TL	HL-H
OFF				
LOW				
HIGH				
COLOR	W	Y	Br	Bl

**HARNESS ROUTING**